

NETSTAR



AVM 4.0 Setting up Operating Hours

This manual describes how to create vehicle operating hours allowing you to report on or receive alerts when vehicles are used outside of these hours.

1 SETTING OPERATING HOURS

Setting up operating hours allow you to report on vehicles that are being used outside of these hours.

To set up “Operating Hours” click on “Manage” from the main page.




From the here select “Vehicles” and “Operating Hours”.



To create new operating hours, click on “New.” at the top right of the page.



Give your operating hours a descriptive name as in the example below:



Choose “Start” and “Finish” times for each day you want to report.

	Start	Finish	Enabled
Monday	05:00		<input type="checkbox"/>
Tuesday	05:00		<input type="checkbox"/>
Wednesday	05:30		<input type="checkbox"/>
Thursday	06:00		<input type="checkbox"/>
Friday	06:30		<input type="checkbox"/>
Saturday	07:30		<input type="checkbox"/>
Sunday	08:00		<input type="checkbox"/>

Once you have selected all the times for the days you want, make sure you click on the “Enabled” radial button for each day and click “Save”.

	Start	Finish	Enabled
Monday	05:00	19:00	<input checked="" type="checkbox"/>
Tuesday	05:00	19:00	<input checked="" type="checkbox"/>
Wednesday	05:00	19:00	<input checked="" type="checkbox"/>
Thursday	05:00	19:00	<input checked="" type="checkbox"/>
Friday	05:00	19:00	<input checked="" type="checkbox"/>
Saturday			<input type="checkbox"/>
Sunday			<input type="checkbox"/>

Now they can be assigned to Vehicles, click on “Vehicles” and then “Details.”

USERS VEHICLES DRIVERS

Details
Groups
Permissions
Operating hours
Classes

From the details page select the Operating Hours that apply to this vehicle.

Vehicle details

Vehicle | Details | Picture and Icon | Vehicle Alerts | Thresholds

Tracker ID: 14583

Serial number: 4642035450

Vehicle Name: Demo 3

Opening (KM):

Vehicle Id:

Operating hours: 7:00am to 6:00pm

Not set

7:00am to 6:00pm

9:00am to 5:00pm Weekend

Weekdays 5:00 to 7:00pm

Odometer

Reading:

Click "Save" to keep the changes you have made.

Thresholds | Save | Cancel

You will now receive alerts when this vehicle operates out of these hours to where the "Vehicle Alerts" are set to send to.

Vehicle details

Vehicle | Details | Picture and Icon | Vehicle Alerts | Thresholds

Email alerts for vehicle

Do Not Send Email Alerts

Inherit from global settings

Send email alerts using these settings

Alert Type	Alert Enabled	Contact	Contact Enabled
Vehicle		David Emergency	Yes
Emergency		David Emergency	Yes
Work		David Emergency	Yes
Locations	No	Not set	No